

a) NUTS / A2 ( SUS 304 S.S. ) INSERT SLOT BY LATHE  
b) SCREWS DRILL HOLES & SAW SLOT BY DRILLING & CUTTING



c) DRILL HOLE IN THE SOCKET RECESS BY A2-70 STAINLESS STEEL